

XP PS Manager

User Manual

Revision 2.14

28 January 2022

Contents

1.0 Introduction	4
2.0 References	4
3.0 Setup	4
3.1 Quick Start Steps.....	4
3.2 PICKit Adapter	4
3.3 XP USB I ² C Adapter.....	5
4.0 Using the XP PS Manager	6
4.1 Adapter Configurations	6
4.1.1 PICKit Serial Adapter.....	6
4.1.2 XP USB I ² C Adapter	8
4.1.2.1 Changing Communication interface	12
4.1.2.2 SCPI Protocol.....	14
4.1.2.3 Multiple 'XP USB I ² C' Adapters.....	16
4.1.3 Multiple interfaces and Protocols.....	17
4.2 Monitor Tab	18
4.2.1 Controlling the device	19
4.2.2 Quick status assessment	19
4.2.3 Device's Information	19
4.2.4 HPx Input Readings (HPT5K0 shown).....	20
4.2.5 HPx Output Readings (HPT5K0 shown).....	20
4.2.6 PMBus Device's Statuses	20
4.2.7 HPx Power Supplies System Statuses	21
4.2.8 Communication Log	22
4.3 Configure Tab.....	23
4.3.1 Vin Group.....	24
4.3.2 Vout Group	24
4.3.3 Iout Group.....	25
4.3.4 Temperature Group.....	25
4.3.5 User Config Group	25
4.3.6 H/W Config Group	26
4.3.7 Addr Config Group	26

4.3.8 Memory Group	27
4.3.9 Power Supply Manufacturer Limits Group.....	28
4.3.11 Power Supply Status	28
4.3.12 Output Reading Group	28
4.3.13 Communication Log Group.....	28
4.4 SCPI Tab.....	29
4.4.1 PMBus Manager Start up with SCPI system	32
4.5 Multi Units Tab	34
4.5.1 Device control	34
4.5.2 Status Displays	35
4.6 Update Firmware Tab	37
Appendix A: HPx Power Supplies Implemented SCPI commands	39
Appendix C: Install/Update XP USB I ² C Device Driver	42
Appendix D: Things to remember	47
Appendix E: PMBus Status Bits Reference	48
Appendix F: XP USB I2C Cable Diagrams	52
Appendix G: Change Log.....	57

1.0 Introduction

This document describes how to control XP Power HPx family of power supplies utilizing 'XP PS Manager' utility program. This program also works with any PMBus compliant devices but 'Manufacturer Specific' commands may not work.

- NOTE:** 1. HPx family = HPT, HPL, HPA, HPF and future designs. HPA1K5PS48 is use as an example in this document.
2. Users of this utility should be familiar with PMBus protocol and its operations.
3. This utility supports both 'PICKit Serial Analyzer' and 'XP Power USB I²C' adapters. The PICKit adapter is limited to I²C/PMBus protocol only. Where the 'XP Power USB I²C' adapter supports RS232, RS485 (half & full duplex) and CAN interface. It also has various protocols, such as, PMBus, Modbus, SCPI and CANopen. The I²C operational differences between PICKit & XP USB I²C adapters are minor, in some displays (adapter name) and the speeds of some executions (scan bus and monitor loops).

2.0 References

1. PMBUS Power System Management Protocol Specification Revision 1.2
2. SMBUS Specification Version 3.0
3. HPT5K0 Communication, Control and Status Specification.
4. Microchip PICKit Serial Analyzer user manual.

3.0 Setup

3.1 Quick Start Steps

For factory fresh HPx power supplies, using PICKit adapter, follow steps in sections

3.2, 4.1.1, 4.2 and 4.2.1.

3.2 PICKit Adapter

1. Connect HPx to PICKit Serial Analyzer as shown in Figure 1 below.
2. Power up HTx, run 'XP PS Manager' utility program.




Figure 1: PICKit interface cable diagram.

3.3 XP USB I²C Adapter

1. Connect HPx to XP USB I²C adapter with desire interface cable (see Appendix F).
Note: Factory fresh units' default is I²C interface.
2. Power up HPx, run 'XP PS Manager' utility program.




Figure 2: I²C connections

4.0 Using the XP PS Manager

4.1 Adapter Configurations





Figure 3: Startup display of the utility (PICKit adapter, no SCPI tap page).

4.1.1 PICKit Serial Adapter


At start up, the utility looks for the last connected adapter.

4.1.1.1 PICKit Not Found

The utility may display 'PICKit Not Found', as shown below.



If switching from XP USB I2C adapter to PICKit, **this utility must be restarted**, as shown in 'Communication Log' window.



If PICKit is connected, try disconnecting and reconnecting USB cable to PICKit adapter. Also try clicking on 'Connection Setting' button, this will force the utility to search for connected adapter. Once the PICKit adapter is detected, the utility will scan for connected power supplies. This will take 4-5 seconds then the 'Connection Setting' window will pop up and display the interface adapter type and the addresses of the connected power supplies. Lowest address is automatically selected.

Connection Setting

Interface Device Adapter

Device Interface: Microchip PICKit Serial Refresh List

Port: I²C Bus PICKit Close Device

Protocol: PMBus

Interface Device Info

Product Code:
Version:
Serial#:
XP Library: -

Master CAN: CANBUS#0

Clock (Hz): 125000

Master Serial: RS485 FD #0

BaudRate: 19200
Parity: Even
Stop Bit: 1

Master I²C: I²C Bus #0

Clock (Hz): 120000
Pull Up (KΩ): None
PEC: ☒

Attached Power Supplies (PSU)

Scanned Power Supply: (Slave Address) 0xB6 0xBA 0xBC 0xBE Scan Bus

Selected Slave Address: 0xB6 (In Hexadecimal, 0xXX). Enter slave address if needed in hex

Power Supply Information

Mfr Id: XP POWER INC	Mfr Date: 20051
Mfr Model: HPA1K5PS048	Mfr Location: Kunshan China
Mfr Rev: 000	Mfr Product Code: 0x0105
Serial #: K20180046	F/W Secondary: 3.11

PSU Serial Configuration

BaudRate: 19200
Parity: Even
Stop Bit: 1
Set Uart*

PSU CAN Bus Configuration

Clock: 125000
Set CAN Bus*

Click "Store User All" button to save PSU configuration into EEPROM.

Store User All*

Close


Note(*): Write Protect must be enabled to update/store PSU configuration. Update PSU configuration before changing Master Configuration. Cycle power to restore default User settings.

'Power Supply Information' of the selected address is displayed, click 'Close' button to return to 'Monitor' tab page (see section 4.2).


4.1.1.2 No Power Supply Found

The utility may display 'No Power Supply found', please check that the I²C interface cable is connected properly, **all** power supply has input power and click on 'Scan Bus' button.

In Multi-Unit connection configuration, I²C bus is held down by an un-powered unit and 'No Power Supply Found' is displayed in 'Slave Adr List' textbox.




Once the power supplies are found, select the address to monitor in 'Slave Adr' combo-box as shown below. Default HPx address is 0xBE, go to section 4.2.




4.1.2 XP USB I²C Adapter

After performing the steps in section 3.3 (using I²C connection), the utility should detect XP USB I²C adapter, scans for connected power supplies and display similar information shown below.




4.1.2.1 XP USB I²C Adapter Not Found

If switching from XP USB I²C adapter to PICKit adapter, the utility will need to be restarted as shown in the 'Communication Log' window below.



If XP USB I²C adapter is connected and the 'Connection' group is displaying one of the errors below, please verify connections cables (interface and USB), input power to the supplies then click on 'Connection Settings' button in 'Monitor' tab page.



The utility will search for connected adapter and scan for connected power supplies. After successful operations, the 'Connection Setting' window will pop-up displaying addresses of the supplies found.

In Multi-Unit connection configuration, I²C bus is held down by an un-powered unit and 'No Power Supply Found' is displayed in 'Slave Adr List' textbox.

Connection Setting

Interface Device Adapter

Device Interface: XP USB I²C S/N: 1 Refresh List

Port: I²C Bus #0 Close Device

Protocol: PMBus

Interface Device Info

Product Code: 16
Version: 1.4
Serial#: 1
XP Library: 1.4

Master CAN: CANBUS#0

Clock (Hz): 125000

Master Serial: RS485 FD #0

BaudRate: 19200

Parity: Even

Stop Bit: 1

Master I²C: I²C Bus #0

Clock (Hz): 120000

Pull Up (K Ω): None

PEC: ☐

Attached Power Supplies (PSU)

Scanned Power Supply: (Slave Address) 0xBA 0xBC 0xBE Scan Bus

Selected Slave Address: 0xBA (in Hexadecimal, 0xXX). Enter slave address if needed in hex

Power Supply Information

Mfr Id: XP POWER Mfr Date: 170320
Mfr Model: HPL5K0TS100 Mfr Location: USA
Mfr Rev: 0002 Mfr Product Code: 0x020A
Serial #: K19320019 F/W Secondary: 9.11

PSU Serial Configuration

BaudRate: 19200

Parity: Even

Stop Bit: 1

Set Uart*

PSU CAN Bus Configuration

Clock: 125000

Set CAN Bus*

Click "Store User All" button to save PSU configuration into EEPROM.

Store User All*

Close

Note(*): Write Protect must be enabled to update/store PSU configuration.
Update PSU configuration before changing Master Configuration. Cycle power to restore default User settings.

Optional: If you have other slow devices on the same I²C bus, select new I²C Clock setting from drop down menu:

Master I²C: I²C Bus #0

Clock (Hz): 120000

Pull Up (K Ω): 10000
25000
50000
100000
120000
200000
300000
400000
500000
600000
700000
800000
900000
1000000

PEC: ☐

If the desire clock rate not shown, type clock rate value in 'Clock (HZ)' box and press enter to set the new clock value.

Master I²C: I²C Bus #0

Clock (Hz): 80000

Pull Up (K Ω): None

PEC: ☐

Check or uncheck 'PEC' (Packet Error Check) box as required by slave unit. HPx power supply family will ignore PEC byte.

At this point, if no change of communication interface is needed, click 'Close' button and go to section 4.2.

Note:

Master Serial & Master CANBus group are inactive (grayed-out) when I²C bus is selected.


The screenshot shows the 'Connection Setting' dialog box. It is divided into several sections:

- Interface Device Adapter:** Contains dropdowns for 'Device Interface' (XP USB I²C S/N: 1), 'Port' (I²C Bus #0), and 'Protocol' (PMBus). There are 'Refresh List' and 'Close Device' buttons.
- Interface Device Info:** A table showing device details:


Product Code:	16
Version:	1.4
Serial#:	1
XP Library:	1.4
- Master CAN:** Includes 'CANBUS#0' and a 'Clock (Hz)' dropdown set to 125000.
- Master Serial:** Includes 'RS485 FD #0', 'BaudRate' (19200), 'Parity' (None), and 'Stop Bit' (1).
- Master I²C:** Includes 'I2C Bus #0', 'Clock (Hz)' (120000), 'Pull Up (KΩ)' (None), and a 'PEC' checkbox.
- Attached Power Supplies (PSU):** Includes 'Scanned Power Supply' (0xB6 0xBA 0xBC 0xBE) and 'Selected Slave Address' (0xB6). A 'Scan Bus' button is present.
- Power Supply Information:** A table showing PSU details:

Mfr Id:	XP POWER INC	Mfr Date:	200510
Mfr Model:	HPA1K5PS048	Mfr Location:	Kunshan China
Mfr Rev:	0002	Mfr Product Code:	0x0105
Serial #:	K20180046	F/W Secondary:	3.11
- PSU Serial Configuration:** Includes 'BaudRate' (19200), 'Parity' (Even), and 'Stop Bit' (1). A 'Set Uart*' button is at the bottom.
- PSU CAN Bus Configuration:** Includes a 'Clock' dropdown set to 125000. A 'Set CAN Bus*' button is at the bottom.
- Store User All*:** A button with a note: 'Click "Store User All" button to save PSU configuration into EEPROM.'
- Close:** A large button at the bottom center.
- Note(*):** Write Protect must be enabled to update/store PSU configuration. Update PSU configuration before changing Master Configuration. Cycle power to restore default User settings.

'Refresh List' button will clear the existing list of adapters and slave addresses. Then search for connected adapters and connected slaves of each adapter. It should be use when adding/removing adapter(s) to the system.



'Close Device' button, when clicked, the selected adapter's resource/handle will be release for other application to use, handy when multiple XP PS Managers are running.



4.1.2.1 Changing Communication interface

To change communication interface, a working communication interface must be established (I²C is the easiest to establish). Click on 'Port' combo-box and select a new interface port from the drop down menu. RS485 Full Duplex port #0 will be used as an example.


Note: Selected port must have corresponding interface chip installed on HPx controller board.

1. Select supported protocol of the interface:

- a. I²C >> PMBus
- b. RS232, RS485, UART >> Modbus, SCPI
- c. CAN >> CANopen
- d. Ethernet >> TCP/IP


Note: RS232 = +/-15V, RS485 = -7/+12V, UART = 0-5V

2. Set the Master interface configuration (BaudRate, Parity, etc.)




NOTE: Master and slave(s) configuration must match.

3. Set the slave (PSU) configuration to match master's configuration (Baud Rate, Parity, etc.).




NOTE: Default parity is set to 'Even'

4. Click on 'Set Uart' button to send configuration to the selected power supply.
5. Click 'Store User All' button to save the configuration



6. If applicable, select other addresses and repeat step 3-5.



7. Click 'Close' button and return to 'Monitor' tab page.
8. At this point, remove the interface cable and connect the new selected interface cable.
9. Click 'Scan' button, wait a few seconds if configuration setup is successful, the address of the slave device(s) would be present and power supply information is displayed.

Attached Power Supplies (PSU)

Scanned Power Supply: 0xB6 0xBA 0xBC 0xBE (Slave Address) Scan Bus

Selected Slave Address: 0xB6 (in Hexadecimal, 0xXX). Enter slave address if needed in hex

Power Supply Information

Mfr Id:	XP POWER INC	Mfr Date:	20051
Mfr Model:	HPA1K5PS048	Mfr Location:	Kunshan China
Mfr Rev:	000	Mfr Product Code	0x0105
Serial #:	K20180046	F/W Secondary:	3.11

NOTE: If unsupported protocol is selected or configuration does not matched, 'Scan Bus' button will display 'No Power Supply found'. Try a difference configuration values or use I²C/PMBus interface to re-establish communication and read/set configuration values (repeat step 1-9). Also see the fine prints below 'Close' button.

Scanned Power Supply: No Power Supply found (Slave Address) Scan Bus

4.1.2.2 SCPI Protocol

The **Standard Commands for Programmable Instruments (SCPI)**; often pronounced "skippy") defines a standard for syntax and commands to use in controlling programmable test and measurement devices used in automated test environment. Procedure to switch to SCPI protocol is shown below. **A combination interface cable of I²C and RS485 would add the convenience to this procedure (no cable switching needed).**

4.1.2.2.1 Switch to SCPI

1. Using established interface communication, in 'Monitor' tab page, ensure that 'WrtEnabl' button indicator is green, click 'Stop Loop' button if 'Read Loop' is active.
2. Click on 'Configuration' tab page, check 'SCPI Protocol' box as shown.

Configuration

Select Addr: 0xBE Set Actual Addr Set Base Addr On/Off On User Cfg: 0x0300 H/W Cfg: 0x01

<input type="checkbox"/> Current SoftStart	<input type="checkbox"/> Disable Fast SoftStart	<input type="checkbox"/> Disable Smart Preload	<input type="checkbox"/> Disable Fan in OFF state	<input type="checkbox"/> RS485 Half-Duplex
<input type="checkbox"/> ACOK Active High	<input type="checkbox"/> DCOK Active High	<input type="checkbox"/> Reserved	<input type="checkbox"/> FANOK/TMPOK Active High	<input checked="" type="checkbox"/> SCPI
<input checked="" type="checkbox"/> Sync	<input checked="" type="checkbox"/> Inhibit Active High	<input type="checkbox"/> Disable Potentiometer	<input type="checkbox"/> Potentiometer 0-105%	
<input type="checkbox"/> Analog Programming	<input type="checkbox"/> Disable Analog Iprog	<input type="checkbox"/> Reserved	<input type="checkbox"/> Reserved	

3. If applicable, repeat step 2 for all devices by selecting slave address from drop down menu.

Configuration

Select Addr: 0xBE Set Actual Addr Set Base Addr On/Off On User Cfg: 0x0300 H/W Cfg: 0x01

<input type="checkbox"/> Current S	<input type="checkbox"/> Disable Fast SoftStart	<input type="checkbox"/> Disable Smart Preload	<input type="checkbox"/> Disable Fan in OFF state	<input type="checkbox"/> RS485 Half-Duplex
<input type="checkbox"/> ACOK A	<input type="checkbox"/> DCOK Active High	<input type="checkbox"/> Reserved	<input type="checkbox"/> FANOK/TMPOK Active High	<input checked="" type="checkbox"/> SCPI
<input checked="" type="checkbox"/> Sync	<input checked="" type="checkbox"/> Inhibit Active High	<input type="checkbox"/> Disable Potentiometer	<input type="checkbox"/> Potentiometer 0-105%	
<input type="checkbox"/> Analog Programming	<input type="checkbox"/> Disable Analog Iprog	<input type="checkbox"/> Reserved	<input type="checkbox"/> Reserved	

4. From 'Monitor' tab page, click on 'Connection Setting' button, the 'Connection Setting' window will pop-up :
 - a. Set 'Port' to RS485 Full-Duplex #0' from drop down menu (as an example).
 - b. Set 'Protocol' to 'SCPI' from drop down menu.

Optional settings shown below if default settings are not satisfactory:

- c. Set 'Master Serial Configuration' parameters (Baud Rate, Parity, Stop-Bit) to match slaves' unit. **Note:** HPx SCPI default is '19200 baud, Even parity, 1 stop bit'.
- d. Set 'Select Slave Address' (0xBA shown).
- e. Set 'PSU Serial Configuration to match the master's configuration.
- f. Click 'Set Uart' button.
- g. Click 'Store User All' button to save the slave configuration
- h. If applicable, select other slave address and repeat steps e to g.
- i. On 'Connection Setting' window, click 'Close' button or you can leave it open and move it to other part of the screen. Switch interface cable to RS485 cable.

Note: 'Scan Bus' and 'MultiUnit' tab are not functional with SCPI protocol.

Connection Setting

Interface Device Adapter

Device Interface: XP USB PC S/N: 1 Refresh List

Port: RS485 Full-Duplex #0 Close Device

Protocol: SCPI

Interface Device Info

Product Code: 16

Version: 1.4

Serial#: 1

XP Library: 1.4

Master CAN: CANBUS#0

Clock (Hz): 125000

Master Serial: RS485 FD #0

BaudRate: 19200

Parity: Even

Stop Bit: 1

Master PC: I2C Bus #0

Clock (Hz): 120000

Pull Up (KΩ): None

PEC: ☐

Attached Power Supplies (PSU)

Scanned Power Supply: 0xB6 0xBA 0xBC 0xBE Scan Bus

(Slave Address)

Selected Slave Address: 0xB6 (in Hexadecimal, 0xFF), Enter slave address if needed in hex

Power Supply Information

Mfr Id: XP POWER INC Mfr Date: 200510

Mfr Model: HPA1K5PS048 Mfr Location: Kunshan China

Mfr Rev: 0002 Mfr Product Code: 0x0105

Serial #: K20180046 F/W Secondary: 3.11

PSU Serial Configuration

BaudRate: 19200

Parity: Even

Stop Bit: 1

Set Uart*

PSU CAN Bus Configuration

Clock: 125000

Set CAN Bus*

Click "Store User All" button to save PSU configuration into EEPROM.

Store User All*

Close

Note(*): Write Protect must be enabled to update/store PSU configuration. Update PSU configuration before changing Master Configuration. Cycle power to restore default User settings.

5. For detail operations on SCPI protocol, see section 4.4.

4.1.2.2.2 Switch from SCPI (back to I²C)

Since HPx power supplies can simultaneously communicate on multiple interface ports, this method sets the utility to establish I²C communication with HPx power supplies (while in SCPI mode) and use it to set the HPx power supplies back to I²C port from SCPI port (RS485, RS232, UART). This method is also applicable to switch back from other communication port (CAN, SPI, etc.).


1. Click on 'Monitor' tap, click on 'Connection Settings' button.
2. Click on 'Port' drop down menu, select 'I²C Bus #0'
3. Click on 'Protocol' drop down menu, select 'PMBus'
4. Click 'Scan Bus' button, ensure that all connected power supplies addresses are shown.
5. Click 'Close' button to close 'Connection Settings' window.
6. Click 'Configure' tab, uncheck 'SCPI' box.
7. If applicable, repeat step 6 for other addresses.

4.1.2.3 Multiple 'XP USB I²C' Adapters

More than one 'XP USB I²C' adapters can be active at the same time. Each adapter can be controlled by its own utility program or by one utility program. Using 'Connection Setting' and 'Device Interface' drop down menu to select a specific adapter to control, as shown below.

Note: Each adapter must have its own communication bus.

Example: 8 HPx power supplies are on adapter S/N 5 another 8 units are on adapter S/N 4.





4.1.3 Multiple interfaces and Protocols

HPx power supplies can handle multiple interfaces & protocols simultaneously. For example, I²C/PMBus for monitoring the HPx parameters, RS485/Modbus for controlling the output voltage and adjusting warning limits or fault limits dynamically.

Note:

- Having multiple interfaces **controlling** the HPx power supplies is not advised but possible.
- The last duplicated command received from any interface overrides the previous one.
For example, I²C set Vout to 45V then RS485 set Vout to 47V, the output is 47V.

4.2 Monitor Tab






Figure 4: Typical 'Monitor' tab screen shot of a running utility.

Select the address to monitor in 'Slave Adr' combo-box as shown below. Default HPT5K0 address is 0xBE.



Click 'Read Loop' button to start monitoring the selected unit. Various parameters are displayed and updates at regular interval, as set by 'Loop Delay' textbox. The output voltage, current and power, device temperatures and fan speed are displayed on dial gauges for quick reference. Graphical representation of these parameters is also presented over time. Read button will change tone/blink when 'Read Loop' is active.

4.2.1 Controlling the device




1. Click 'WrtEnabl' button to let the device accept commands, LED indicator turns green.
2. Type the desired output voltage in 'Vout' box and press 'Enter' key.
3. Enter output current limit in 'Iout Limit' box.
4. Click 'PS ON' button to enable the device output, LED indicator turns green.
5. Optional: enter a value in 'Fan' box for a constant fan speed.

Note: If the device's temperature rises above pre-program limit, automatic fan speed control will override the set fan speed. For automatic fan control, enter '0' in 'Fan' box.

6. 'Tx Global Cmd' check box: If checked, device address of the write commands will be set to '00'. This caused all devices on the bus to implement the command. This check box is duplicated in 'Configure' tab.

4.2.2 Quick status assessment



Dials representing output voltage, current and power, PFC temperature, Secondary stage temperature and fan speed with warning limits (yellow) and fault limits (red) are shown to quickly access the status of the supply. Last 90 seconds of output voltage, current and temperatures are also shown over time in graphical form. For unit with multiple fans, FAN gauge only displays FAN1 RPM.

4.2.3 Device's Information



Standard PMBus information is displayed in the 'Information' section. Some

'Manufacturer Specific' information are also displayed (Run-Time, Firmware Revision).

4.2.4 HPx Input Readings (HPT5K0 shown)

Input Readings					
Vin1 Pk(V):	679		DCBus1(V):	783	
Vin2 Pk(V):	681		DCBus2(V):	783	
Vin3 Pk(V):	682		DCBus3(V):	793	
PFC1 T(°C):	34		DCBus1Adj:	164	
PFC2 T(°C):	34		DCBus2Adj:	164	
PFC3 T(°C):	31		DCBus3Adj:	174	

Each stage of the input phase is shown in this group. The indicator will turn red when its parameters exceeds pre-set limits.

4.2.5 HPx Output Readings (HPT5K0 shown)

Output Readings (Vout Mode=0x18), STATE = ON					
Vout(V):	99.99		Iout 1/2/3(A):	2.09 / 2.03 / 2.06	
Iout(A):	5		Fan1/2(RPM):	1472 / 0	
Pout(W):	496.5		Fan3/4(RPM):	0 / 0	
SEC1 T(°C):	40		FanCmd/Cnt(%):	0/26	
SEC2 T(°C):	38		PoutMax(W):	5000	
SEC3 T(°C):	35				

Higher resolution readings are displayed in this section. Output current and temperature of each input phase are shown here. Round indicator turns red when its parameter exceeds pre-set limits. For unit with multiple fans, their speed is shown in corresponding 'Fan1/2' & 'Fan3/4' lines. FAN gauge only displays FAN1's speed.

4.2.6 PMBus Device's Statuses

Status			Pmbus Status:		System Status:		SD_EVENT3		SD_EVENT2		SD_EVENT1		SD_EVENT0	
STATUS_WORD	STATUS_BYTE	STATUS_VOUT	Word: 0x0000	SD Event: 0x00000000	FAN_FLT	VOUT_UV_FLT	HDW_OVP_FLT	VIN1_FLT						
UNKNOWN	NONE	TRACKING	Byte: 0x00	Last SD Event: 0x00000000	PFC_OTP	LATCHED_FLT	USER_OVP_FLT	VIN2_FLT						
OTHER	CML	TOFF_MAX_WRN	Vout: 0x00	Status: 0x00A9080C	REMOTE_OFF	PFC1_OTP	SW_OVP_FLT	VIN3_FLT						
FANS	TEMP	TON_MAX_FLT	Iout: 0x00		CMD_OFF	PFC2_OTP	Reserved	VIN_DMBALANCE						
PWR_GOOD	VIN_UV	VOUT_MAX_WRN	Input: 0x00	PFC Status/Fault:	IOUTX_OCP	PFC3_OTP	IOUTX_DMBALA_	PFC1_FLT						
MFR_SPEC	IOUT_OC	VOUT_UV_FLT	Temp: 0x00	PFC1: 0x00/0x00	PRI_COM1_FLT	SEC1_OTP	HDW_OCP_FLT	PFC2_FLT						
INPUT	VOUT_OV	VOUT_UV_WRN	Cml: 0x00	PFC2: 0x00/0x00	PRI_COM2_FLT	SEC2_OTP	SW_OCP_FLT	PFC3_FLT						
IOUT/POUT	OFF	VOUT_OV_WRN	Fan12 0x00	PFC3: 0x00/0x00	PRI_COM3_FLT	SEC3_OTP	FAULT_HOLD	PRI_OVP_FLT						
VOUT	BUSY	VOUT_OV_FLT	Fan34 0x00	Note: Click on Status value to see bits details										
			Mfr: 0x00	Clear Fault										
			Other: 0x00											

Figure 5: Normal operation = all statuses are 'green' or 0x00.

Main status bits are displayed in round LED indicator, Green = good, Red = bad.

Other status registers are shown in hexadecimal value under 'PMBus Status' column. Please refer to PMBus Specification for more details, a condense status bits definitions are shown in Appendix D.

Note: Bit0 = Top row, bit7 = Bottom row

Status			Pmbus Status:		System Status:	
STATUS_WORD	STATUS_BYTE	STATUS_VOUT	Word: 0x284A	SD Event: 0x00000077		
UNKNOWN	NONE	TRACKING	Byte: 0x4A	Last SD Event: 0x00000000		
OTHER	CML	TOFF_MAX_WRN	Vout: 0x00	Status: 0x00090000		
FANS	TEMP	TON_MAX_FLT	Iout: 0x00	PFC Status/Fault:		
PWR_GOOD	VIN_UV	VOUT_MAX_WRN	Input: 0x30	PFC1:	0x00/0x09	
MFR_SPEC	IOUT_OC	VOUT_UV_FLT	Temp: 0x00	PFC2:	0x00/0x09	
INPUT	VOUT_OV	VOUT_UV_WRN	Cml: 0xC0	PFC3:	0x00/0x09	
IOUT/POUT	OFF	VOUT_OV_WRN	Fan12 0x00	Note: Click on		
VOUT	BUSY	VOUT_OV_FLT	Fan34 0x00	Status value to		
			Mfr: 0x00	see bits details		
			Other: 0x00	<div>Clear Fault</div>		

Figure 6: When faults are detected, indicators turn 'red' and status values are non-zero and in red also.

These fault indicators are latched until cleared by the 'Clear Fault' button. 'Clear Fault' button resets all fault indicators to 'green', if fault(s) still exists, the indicator will turn 'red' again.

Status

STATUS_WORD	STATUS_BYTE	STATUS_CML
UNKNOWN	NONE	MEM_LG_FLT
OTHER	CML	OTH_COM_FLT
FANS	TEMP	Reserved
PWR_GOOD	VIN UV	CPU_FLT
MFR_SPEC	IOUT_OC	MEM_FLT
INPUT	VOUT_OV	PEC_FAILED
IOUT/POUT	OFF	INV_DATA
VOUT	BUSY	INV_CMD

PmBus Status:

Word: 0x0002
 Byte: 0x02
 Vout: 0x00
 Iout: 0x00
 Input: 0x00
 Temp: 0x00
 Cml: 0x80
 Fan12 0x00
 Fan34 0x00
 Mfr: 0x00
 Other: 0x00

Status

STATUS_WORD	STATUS_BYTE	STATUS_IOUT
UNKNOWN	NONE	POUT_OP_WRN
OTHER	CML	POUT_OP_FLT
FANS	TEMP	PWR_LIMIT
PWR_GOOD	VIN UV	ISHARE_FLT
MFR_SPEC	IOUT_OC	IOUT_UC_FLT
INPUT	VOUT_OV	IOUT_OC_WRN
IOUT/POUT	OFF	IOUT_OCLV_FLT
VOUT	BUSY	IOUT_OC_FLT

PmBus Status:

Word: 0x0002
 Byte: 0x02
 Vout: 0x00
 Iout: 0x00
 Input: 0x00
 Temp: 0x00
 Cml: 0x80
 Fan12 0x00
 Fan34 0x00
 Mfr: 0x00
 Other: 0x00

Note: Click on Status value to see bits details

Clear Fault

A status detail is shown on the 3rd panel when individual status value is clicked, as indicated next to the 'Clear Fault' button. STATUS_CML and STATUS_IOUT are shown in the 3rd panel above.

4.2.7 HPx Power Supplies System Statuses

Shutdown events represented by round indicators shown above. Grey = normal, Red = faulted. Click on 'Last SD' value to see last shutdown events.

System Status:

SD Event: 0x00000000
 Last SD Event: 0x00000000
 Status: 0x00A9080C

PFC Status/Fault:

PFC1: 0x00/0x00
 PFC2: 0x00/0x00
 PFC3: 0x00/0x00

Note: Click on Status value to see bits details

Clear Fault

SD_EVENT3	SD_EVENT2	SD_EVENT1	SD_EVENT0
FAN_FLT	VOUT_UV_FLT	HDW_OVP_FLT	VIN1_FLT
PFC_OTP	LATCHED_FLT	USER_OVP_FLT	VIN2_FLT
REMOTE_OFF	PFC1_OTP	SW_OVP_FLT	VIN3_FLT
CMD_OFF	PFC2_OTP	Reserved	VIN_IMBALANCE
IOUTX_OCP	PFC3_OTP	IOUTX_IMBALA..	PFC1_FLT
PRI_COM1_FLT	SEC1_OTP	HDW_OCP_FLT	PFC2_FLT
PRI_COM2_FLT	SEC2_OTP	SW_OCP_FLT	PFC3_FLT
PRI_COM3_FLT	SEC3_OTP	FAULT_HOLD	PRI_OVP_FLT

Similarly, click on 'Status' value will display the details of the system status, as shown below. Grey = normal/not enabled, Green = enabled, Red = faulted

System Status:

SD Event: 0x00000000
 Last SD Event: 0x00000000
 Status: 0x00A9080C

PFC Status/Fault:

PFC1: 0x00/0x00
 PFC2: 0x00/0x00
 PFC3: 0x00/0x00

Note: Click on Status value to see bits details


Clear Fault

SYS_STATUS3	SYS_STATUS2	SYS_STATUS1	SYS_STATUS0
Reserved	DCBUS_ADJ	TEMP_COLD	IN_CURRENT_LI..
PFC_OTP	SOFT_START	VOUT_UV	IN_PWR_LIMIT
PFC1_OTP	PRELOAD_OVE..	ANALOG_PROG	VIN_HIGH_LINE
PFC2_OTP	PRELOAD_ENA..	VSTBY_ENABLE	PWM_ENABLE
PFC3_OTP	Reserved	CURRENT_WAL..	OTP_WARNING
SEC1_OTP	ISHARE_ENABLE	HDW_OVP_TEST	OTP_FLT
SEC2_OTP	Reserved	SEC_CALIBRATI..	TEMP_TOO_COLD
SEC3_OTP	DOCK_FAST	PRI_CALIBRATI..	FAN_FLT

Click on 'PFC1' value will display the details of the PFC1 shutdown and status, none, as shown below.

System Status: SD Event: 0x00000000 Last SD Event: 0x00000000 Status: 0x00A9080C PFC Status/Fault: PFC1: 0x00/0x00 PFC2: 0x00/0x00 PFC3: 0x00/0x00 <input type="button" value="Clear Fault"/>		PFC1_SD <input type="checkbox"/> AC_UV_FLT <input type="checkbox"/> AC_OV_FLT <input type="checkbox"/> PFC_LATCH_FLT <input type="checkbox"/> PFC_UV_FLT <input type="checkbox"/> PFC_OV_FLT <input type="checkbox"/> PFC_LOW_FLT <input type="checkbox"/> PFC_OT_FLT <input type="checkbox"/> PFC_RMT_OFF		PFC1_SD_LAST <input type="checkbox"/> AC_UV_FLT <input type="checkbox"/> AC_OV_FLT <input type="checkbox"/> PFC_LATCH_FLT <input type="checkbox"/> PFC_UV_FLT <input type="checkbox"/> PFC_OV_FLT <input type="checkbox"/> PFC_LOW_FLT <input type="checkbox"/> PFC_OT_FLT <input type="checkbox"/> PFC_RMT_OFF		PFC1_STATUS <input type="checkbox"/> PFC_READY <input type="checkbox"/> PFC_RLY_CLOSE <input type="checkbox"/> AC_UV_QUICK <input type="checkbox"/> PFC_ON <input type="checkbox"/> HIGH_LINE <input type="checkbox"/> PFC_OT_WRN <input type="checkbox"/> PFC_BOOST_FAIL <input type="checkbox"/> PFC_CALIBRATI...		- <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	
---	--	---	--	--	--	--	--	--	--

4.2.8 Communication Log



This window display communication errors, read/write, device address, command that has the error and total error count. 'Communication Log' window is duplicated in 'Configure' tab.

'Clear' button will clear the displayed errors but will not reset error counter, restart this utility will.

Using horizontal scroll bar to read the entire error line.

Note: Once the communication is lost, PICKit adapter **may** need to be reset (cycle power) and using 'Connection' button to re-establish communication. If all else failed, this utility program may need to be restarted

4.3 Configure Tab

The screenshot shows the 'Configure' tab in the XP PS Manager software. The interface is divided into several sections:


- Vin Section:** Contains tables for Warning, Fault, Response, Response Type, Retry Setting, and Delay Time for Over Voltage (V) and Under Voltage (V).
- Vout Section:** Includes Vout status (On), Vout Cmd (V), Vout Mode, RampUp(mS), and RampDn(mS). It also has a table for Warning, Fault, Response, Response Type, Retry Setting, and Delay Time for Over Voltage (V) and Under Voltage (V).
- Iout Section:** Includes a table for Warning, Fault, Response, Response Type, Retry Setting, and Delay Time for Over Current (A) and Under Current (A).
- Temperature Section:** Includes a table for Warning, Fault, Response, Response Type, Retry Setting, and Delay Time for Over Temp (°C) and Under Temp (°C).
- Addr Config Groupbox:** Shows the selected address (0xB6) and various configuration options like Set Base Addr, Set Actual Addr, and various checkboxes for Analog Prog, Sync, ACOK Active High, etc.
- Memory Section:** Includes Write Protect, User Data 0, User Data 1, and buttons for Read All Cfgs, Store User All, ReStore User All, and ReStore Deflt All.
- Power Supply Manufacturer Limits:** A table showing limits for Vin Min/Max, Vout Min/Max, Iin Max, Pin Max, Temp Min/Max, etc.
- Power Supply Status (Extended):** A table showing status for SEC Temp, PFCs Temp, Min. Fan Speed, Vin RMS, Voltage Output, Current Output, Power Output, and STATUS.
- Output Readings:** A table showing readings for Vout(V), Iout(A), Pout(W), SEC1 T(°C), SEC2 T(°C), SEC3 T(°C), Iout1(A), Iout2(A), Iout3(A), Fan(RPM), FanCmd/Ctrl(%), and PoutMax(W).
- Communication Log:** A window showing the error message: 'Err8: Access Denied, no update, Write Protected!'.

Note: Write limit or parameter into the corresponding box and type 'Enter' to initiate the write/update sequence. For Fault Response you can also modify setting using the drop down list. Write/Update will be done automatically after selection. Read back is done after any writes and will update the corresponding field.

Figure 7: Configuration parameters of the selected address (0xB6 shown in 'Addr Config' groupbox).

This tab allows user to change warning limits, fault limits, fault responses and save these limits to user's setting. Please read the 'fine print' on the bottom of the tab. ☺

Note: Some fault responses are hard-coded and will not accept invalid/unsupported selections. 'Communication Log' window will display error message "Err8".



OVP fault response is hard-coded to 'Disable' with 'No Retry', see section 4.3.2.

4.3.1 Vin Group

Vin		Warning	Fault	Response	Response Type	Retry Setting	Delay Time
Over Voltage (V):	536	540	0xC0	Disable, Resume when OK	No Retry	0 ms	
Under Voltage (V):	175	170	0x77	Delay response, Retry	6 Retries	70 ms	
Vin ON (V):		Vin OFF (V):					

Input 'Over Voltage' and input 'Under Voltage' warning and fault parameters are set to default values and cannot be modified. However, the 'Response Type', 'Retry Setting' and 'Delay Time' can be modified by selecting the drop-down menu when you click on the combo-box as shown below.

Response Type

Delay response, Retry

Delay response, Retry

Continue operation

Delay response, Retry

Disable, Retry

Disable, Resume when OK

Retry Setting

No Retry

6 Retries

No Retry

1 Retry

2 Retries

3 Retries

4 Retries

5 Retries

6 Retries

20 Retries

Delay Time

0 ms

70 ms

0 ms

10 ms

20 ms

30 ms

40 ms

50 ms

60 ms

70 ms

4.3.2 Vout Group

Vout		Warning	Fault	Response	Response Type	Retry Setting	Delay Time
Vout:	On	Vout Cmd (V): 48.04	Vout Mode: 0x16	RampUp(mS): 40	RampDn(mS): 40		
Over Voltage (V):	50.0	51.0	0x80	Disable, Retry	No Retry	0 ms	
Under Voltage (V):	46.0	45.0	0x00	Continue operation	No Retry	0 ms	

Each parameter can be changed by highlighting the value in the corresponding text box and typing in the new value then pressing the 'Enter' key to transmit the command to the device. Similarly, 'Response' behavior can be modified with the drop-down menu.

Vout command, warning and fault limits should be set as follows:

$$UV_FAULT < UV_WARN < Vout < OV_WARN < OV_FAULT$$

If not, Vout command may cause shutdown when it is set below UV_FAULT limit and fault response is set to 'Disable'.

Note:

1. Over Voltage Fault response is hard-coded to immediate shutdown and the fault is latched. To clear OVP is to turn the power supply off and on using 'PS ON' button in the 'Monitor' tab.
2. On recovery retries, HPT5K0 wait 1 second (for internal filters and voltages to stabilize) before start checking for faults. So, 5 retries will take 5 seconds + delay between retries.

4.3.3 Iout Group

	Warning	Fault	Response	Response Type	Retry Setting	Delay Time
Over Current (A):	88	90	0x00	Continue operation	No Retry	0 ms
Under Current (A):						
Over Current Low Voltage (OCLV, V):			0			

Under Current response are not implemented. Other parameters can be change in the same manners as with other groups.

4.3.4 Temperature Group

	Warning	Fault	Response	Response Type	Retry Setting	Delay Time
Over Temp (°C):	120	125	0xC0	Disable, Resume when OK	No Retry	0 ms
Under Temp (°C):						
PFC Over Temp (°C):	86	90				
				Fan Min Control (%)		0

Under Temperature responses are not implemented. Other parameters can be change in the same manners as with other groups.

4.3.5 User Config Group

User Config			
User Cfg: 0x0300			
<input type="checkbox"/> Analog Program	<input checked="" type="checkbox"/> Sync	<input type="checkbox"/> ACOK Active High	<input type="checkbox"/> Current SoftStart
<input type="checkbox"/> No Analog Iprog	<input checked="" type="checkbox"/> Inhibit Active High	<input type="checkbox"/> DCOK Active High	<input type="checkbox"/> No Fast SoftStart
<input type="checkbox"/> No Analog Vprog	<input type="checkbox"/> No Potentiometer	<input type="checkbox"/> Reserved1	<input type="checkbox"/> No Smart Preload
<input type="checkbox"/> No Preload in SD	<input type="checkbox"/> Potentiometer 0-105%	<input type="checkbox"/> FAN/TMP OK Active Hi	<input type="checkbox"/> No Fan in OFF state

Check each box to activate its behavior. Some features are HPx power supplies specific, some are PMBus standard.

Analog Programming: J401 pin 19 (VPROG) is used to control output voltage by applying 0-5VDC.

No Analog Iprog: J401 pin 22 (IPROG) is disabled.

No Analog Vprog: J401 pin 19 (VPROG) is disabled

No Preload in SD: Pre-Load is disabled on shutdown (Vout slowly float down to 0V @ no load).

Sync: J401 pin 18 is utilized by paralleled units to enable output voltage simultaneously.

Inhibit Active High: Vout is set to 0V when this signal is high.

No Potentiometer: Vout cannot be controlled by back panel potentiometer.

Potentiometer 0-105%: The back-panel potentiometer adjusts Vout from 0V to 105% of nominal value.

If unchecked, potentiometer adjusts Vout to +/-10% of set Vout value.

ACOK Active High: When AC stage is in normal operation, this signal will be high.

DCOK Active High: When DC stage is ready to supply output voltage, this signal will go high.

Reserve1: Reserved for future function.

FANOK/TMPOK Active High: If fan speed and temperature are as expected, this signal will be high.


Current Soft Start: Output current is ramp up slower than normal, ~200mS to full load.

No Fast Soft Start: Vout will rise to the set value as fast as possible otherwise ~35mS rise time.

No Smart Preload: Preload circuit is used to speed up output voltage fall time.

No FAN in OFF state: Fan will also be off when OPERATION set to off, if temperature allowed.


4.3.6 H/W Config Group



RS485 Half-Duplex: If checked, the utility will send command to the HPx power supplies to communicate via RS485 Half-Duplex interface. If not checked, RS485 Full-Duplex will be utilized (default).

SCPI: If checked, the utility will send the command to HPx power supplies to use 'Standard Command for Programmable Instrument' protocol. This is applicable to RS232, RS485 interface only (XP USB I2C adapter). If not checked, Modbus protocol will be used (default).

4.3.7 Addr Config Group



Select Address: Using drop down menu to select available address to communicate with.


Set Base Addr: Change base address, the utility will automatically masks 3 LSB to 0's.

Note: User must save the new address/base address via 'Store User All' button.

Set Actual Addr: Change unit address to the value entered (0x02-0xFE), A0, A1, A2 pins are ignored.

Enter 00 = base address + (A0, A1, A2) (base address factory default is 0xB0).

4.3.8 Memory Group



This is where you save and recall various parameter values.

Write Protect: must be disabled (set to 0x00) before any command will be accepted.

'User Data0': Enter 16 characters maximum here.

'User Data1': Enter 16 characters maximum here.

'Read All Cfg' button: Read all parameter values from power supply.

'Store User All' button: Save all parameter values to user's memory.

'ReStore User All' button: Set all parameter values to user's memory values.

'ReStore Deflt All' button: Set all parameter values to factory's default values.

'Tx Global Cmd' box: If checked, device address of the write commands will be set to '00' for all devices.

'Script Function Select' button: Select script file from C:\HPT5K0_Scripts directory (default) to execute.

'Run' button: Execute the selected script file. Example script file is included in the installation. It is a convenient tool to configure multiple power supplies to the same configuration. See Appendix B for script file example.

4.3.9 Power Supply Manufacturer Limits Group

Power Supply Manufacturer Limits			
Vin Min (V):	90	Vout Min (V):	0.0
Vin Max (V):	264	Vout Max (V):	50.4
Iin Max (A):	16	Iout Max (A):	32
Pin Max (W):	1700	Pout Max (W):	1500
Temp Min (°C):	-20	Temp Max (°C):	50

This group displays factory's value for the limits shown and cannot be altered.

4.3.11 Power Supply Status

Power Supply Status (Extended)			
SEC Temp. Max. (°C):	27	Voltage Output (V):	55.03
PFCs Temp. Max. (°C):	28	Current Output (A):	0.97
Min. Fan Speed (RPM):	1184	Power Output (W):	51.5
Vin RMS (V):	217	STATUS:	0x0000

This group duplicates 'Monitor' tab page information, shown here for convenient.

4.3.12 Output Reading Group


Output Readings			
Vout(V):	60.0	Iout1(A):	2.09
Iout(A):	6.16	Iout2(A):	2.34
Pout(W):	369	Iout3(A):	2.56
SEC1 T(°C):	37	Fan(RPM):	1408
SEC2 T(°C):	34	FanCmd/Ctrl(%):	0/23
SEC3 T(°C):	31	PoutMax(W):	5000

This group duplicates 'Monitor' tab page information, shown here for convenient.

4.3.13 Communication Log Group

Duplication of 'Monitor' tab presented here for convenience.

Note: 'Clear' button in any tab will clear Communication Log windows in all tabs.



4.4 SCPI Tab


See section 4.1.2.2.1 for switching to SCPI protocol instruction.

The screenshot shows the 'SCPI' tab in the XP PS Manager software. The interface includes a 'Basic SCPI I/O' section with a 'Select SCPI Command' dropdown menu and a 'Slave Add (Hex):' dropdown menu set to '0xBE'. Below these is a text area for entering commands. To the right is an 'SCPI Error log' text area. At the bottom of the 'Basic SCPI I/O' section are buttons for 'Write', 'Query', 'Read', 'Read Status Byte', 'Scan', and 'CLEAR'. Below this is an 'SCPI Communication Log' text area. At the very bottom, there is a 'Script File' text field, 'Select Script', 'Execute Script', and 'Loop Script' checkboxes, and a 'CLEAR LOG' button.


1. Select 'Slave Add' from drop down menu, :INSTRUMENTSElect command is transmitted as shown.
Note: ':INSTRUMENTSElect' command will not be issued if SCPI protocol is not active.

This is a close-up screenshot of the 'Basic SCPI I/O' section. The 'Select SCPI Command' dropdown is set to ':INSTRUMENTSElect #HBE'. The 'Slave Add (Hex):' dropdown is set to '0xBE'. The text area below contains the command ':INSTRUMENTSElect #HBE'. The buttons 'Write', 'Query', 'Read', 'Read Status Byte', 'Scan', and 'CLEAR' are visible at the bottom.

2. Select '*IDN?' from drop down menu.




3. Click 'Query' button, information of the selected slave unit is displayed in log window.




4. Click on 'Select Script' button and select one of the SCPI script file.

Sample scripts files are provided with the installation of this utility.






Click on 'Execute Script' button. The communication log of the script execution is display in the 'SCPI Communication Log' window, shown below.



5. 'Loop Script' check-box, if checked will continuously run the selected script file.

A small rectangular button with the text "Loop Script:" followed by an unchecked checkbox.

At this point, user must be familiar with SCPI protocol's read and write commands to control the HPx power supply. Appendix A lists HPx's implemented SCPI commands.

Note: Command ':INSTrument:SELEct #HBE' on the first line of the script sets slave address to 0xBE for all of the commands that follows.

4.4.1 PMBus Manager Start up with SCPI system

When the communication protocol is already running in SCPI protocol, ignore the 'Monitor' tab start up page information. Click on SCPI tab and perform scan function to find SCPI slave addresses.



A screenshot of the SCPI interface. At the top, it says "Basic SCPI I/O". Below this are two dropdown menus: "Select SCPI Command:" and "Slave Addr (Hex):", separated by "or". Below the first dropdown is a text area with the instruction "Enter Command below (command below will be executed using the button just below):". To the right of the text area is an "SCPI Error log:" label above a text area. Below the text area are six buttons: "Write", "Query", "Read", "Read Status Byte", "Scan", and "CLEAR". To the right of these buttons is a "CLEAR" button. Below the buttons is a large text area labeled "SCPI Communication Log:". At the bottom, there is a "Script File:" label above a text input field, followed by "Select Script", "Execute Script", and "Loop Script:" with an unchecked checkbox. A "CLEAR LOG" button is located at the bottom right.

Figure 8: Blank SCPI page upon start up with SCPI protocol already running.

1. Click on 'Configure' tab and set 'Base Addr' value as starting scan address, 0xB0 shown (default).

A small dialog box titled "Addr Config". It contains three labels: "Select Addr:" with a dropdown menu showing a downward arrow; "Set Base Addr:" with a text input field containing "0xB0"; and "Set Actual Addr:" with a text input field containing "0x00".

2. Click on 'SCPI' tab and click on 'Scan' button. Scan function will issue 'IDN?' query command starting with 'Base Addr' to 'Base Addr'+0x0E with even address values. (0xB0, 0xB2, 0xB4... 0xBE). The responding slave address is added to the 'Slave Addr' combo-box. Selecting a slave address from the combo-box drop down menu to control its functions.




Figure 9: Scan function completed display. Only 0xB6, 0xBA, 0xBC and 0xBE show response to the query command.

Sample SCPI script 'SCPI_Scan_#HBx_Addr.txt' performs the same scan function but will not save the responding addresses to the 'Slave Addr' combo-box.

4.5 Multi Units Tab

'Multi Units' tab displays essential parameters of all power supplies (up to 8 units) that are connected to the I²C bus. The parameters for all devices are constantly read with pause period set by 'Loop Delay' value in the 'Monitor' tab.

4.5.1 Device control


	PSU #0	PSU #1	PSU #2	PSU #3	PSU #4	PSU #5	PSU #6	PSU #7
Address/ID	0xB6	0xBA	0xBC	0xBE	0x00	0x00	0x00	0x00
Monitor	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
MFR MODEL	HPA1K3PS048	HPL5K0TS100	XP POWER	HPL5K0TS48				
MFR SERIAL	K20100046	K19320019		K21450001				
OPERATION	ON	ON	ON	ON				
WRITE PROTECT	All cmds	All cmds	Protect None	All cmds				
VOUT MODE	0x16	0x18	0x18	0x18				
VOUT COMMAND	48.04	25.0	50.0	12.0				
IOUT OCP LIMIT	35	54	27	113				
POUT MAX	1400	5000	5000	3400				
FAN COMMAND	0	0	0	0				
VIN PK	117	0	0	0				
VOUT	48.03	0.0	0.0	0.0				
IOUT	0	0	0	1294				
POUT	0	0	0	0				
TEMP1	31	-32	-32	-32				
FAN SPEED	4160	0	0	0				
STATUS_WORD	0x0000	0x2848	0x0A40	0x0840				
STATUS_VOUT	0x00	0x00	0x00	0x00				
STATUS_IOUT	0x00	0x00	0x00	0x00				
STATUS_INPUT	0x00	0x00	0x00	0x00				
STATUS_CML	0x00	0x00	0x00	0x00				
STATUS_TEMP	0x00	0x00	0x00	0x00				
STATUS_FAN12	0x00	0x00	0x00	0x00				
STATUS_MFR	0x00	0x00	0x00	0x00				
CLEAR FAULT	Clear Fault	Clear Fault	Clear Fault	Clear Fault	Clear Fault	Clear Fault	Clear Fault	Clear Fault

Figure 10: Two power supplies connected to the same I²C bus shown.

'Monitor' Check box: When checked, the corresponding device's parameters are updated.

'On/Off' buttons: When clicked, the output voltage of the corresponding device is toggle between enable and disable state (0 volt or commanded volts).

'WRITE PROTECT' buttons: Select command protection level from the drop down menu items.



The intended way to read these cells is:

WRITE PROTECT >> Protect None = all commands are writable

Hovering the mouse over the model number cell displays the full model number.

Example shown below is a 'Modified Standard' model.

	PSU #0	PSU #1	PSU #2
Address/ID	0xBA	0xBE	0x00
Monitor	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
MFR MODEL	HPT5K0TS100	HPT5K0TS100-XT129...	
MFR SERIAL	K18380023 ...	K18130018 ...	
OPERATION	ON	ON	
WRITE PROTECT	Protect None	Protect None	
VOUT MODE	0x18	0x18	
VOUT COMMAND	100 A	100 A	

4.6 Update Firmware Tab

This tab is a simplified way to download new firmware to HPx family of power supplies. Ensure that the power supply has boot loader code programmed into the controller boards (primary & secondary). Error is produce if not.

The screenshot shows the 'UpdateFirmware' tab in the XP PS Manager interface. At the top, there are tabs for 'Monitor', 'Configure', 'SCPI', 'MultiUnits', and 'UpdateFirmware'. The 'UpdateFirmware' tab is active. Below the tabs, there are three numbered steps: 1. 'Select Operation >>>' with a dropdown menu showing 'click for menu >>>'. 2. 'Select firmware file >>>' with two buttons: 'Select Firmware File' and 'Select Firmware file'. 3. 'Click 'Update Firmware' button' with an 'Update Firmware' button. Below these steps is a 'Status' section with a large white area for displaying status information. At the bottom left, there is a 'Clear' button.

1. Select slave address of the HPx unit to be updated from 'Monitor' tab.
2. Select from drop down menu which firmware to update.

The image shows a close-up of the '1. Select Operation >>>' dropdown menu. The menu is open, showing two options: 'Primary' and 'Secondary'. The 'Secondary' option is selected and highlighted in blue. Below this, the same dropdown menu is shown with 'Secondary' selected.

Secondary selected.

3. Select firmware file (.hex) file to update.



4. Click 'Update Firmware' button. Operation is completed when 'Unit is running application firmware' is displayed.

Verify that 'App Calculated Checksum' value is the same as 'Stored Checksum' value in the status textbox.

Goto 'Monitor' tap page to verify that the HPx unit is operating normally.



Appendix A: HPx Power Supplies Implemented SCPI commands

Note: Lower case letters can be omitted, e.g. :CURREnt = :CURR, :CURREnt:AMPLitude = :CURR:AMPL

:CURREnt

:CURREnt:AMPLitude

:CURREnt:AMPLitude?

:CURREnt:PROTection

:CURREnt:PROTection?

:CURREnt?

:INSTrument:NSElect

:INSTrument:NSElect?

:INSTrument:SElect

:INSTrument:SElect?

:MEASure:CURREnt?

:MEASure:POWer?

:MEASure:TEMPerature?

:MEASure:VOLTagE?

:OUTPut:STATe

:OUTPut:STATe?

:PMBUs

:PMBUs?

:STATus:OPERation:CONDition?

:STATus:OPERation:ENABle

:STATus:OPERation:ENABle?

:STATus:OPERation:EVENT?

:STATus:OPERation?

:STATus:PRESet

:STATus:QUEStionable:CONDition?

:STATus:QUEStionable:ENABle

:STATus:QUEStionable:ENABle?

:STATus:QUEStionable:EVENT?

:STATus:QUEStionable?

:SYSTem:CAPability?

:SYSTem:ERRor?

:SYSTem:VERSion?

:VOLTage

:VOLTage:AMPLitude

:VOLTage:AMPLitude?

:VOLTage:LIMit:LOW

:VOLTage:LIMit:LOW?

:VOLTage:PROTection:LEVel

:VOLTage:PROTection:LEVel?

:VOLTage?

Appendix B: Script file example

```
REM This sample script file is for HPA1K5PS24
REM script line format:
REM PMBusCommand, value
REM 0xYY for hex value (ie; 0xAB)
REM See user manual for details
REM Optional: MFR_PRODUCT_CODE on 1st command line
REM ----- NO BLANK LINE! (use REM) -----
REM
MFR_PRODUCT_CODE, 0x0102
WRITE_PROTECT, 0x00
VOUT_COMMAND, 20
VOUT_UV_WARN_LIMIT, 7
VOUT_UV_FAULT_LIMIT, 4
REM Add more commands as needed
REM Add more commands as needed
VOUT_OV_FAULT_LIMIT, 22
STORE_USER_ALL, 0
WRITE_PROTECT, 0x80
Exit
```

NOTE: MFR_PRODUCT_CODE is optional. If present, script will not be executed if connected supply's code does not match.

This is optional safety to prevent model specific script to run on other models.

You can have non-specific/generic scripts (*no MFR_PRODUCT_CODE command line*) that can be run for all models.

Product Code: (as of April 2020)

HPA1K5PS24: 0x0102	HPL5K0TS048: 0x0205	HPT5K0TS048: 0x0005	HPT5K0TS048-L: 0x8005
HPA1K5PS48: 0x0105	HPL5K0TS060: 0x0206	HPT5K0TS060: 0x0006	HPT5K0TS060-L: 0x8006
	HPL5K0TS100: 0x020A	HPT5K0TS100: 0x000A	HPT5K0TS100-L: 0x800A
	HPL5K0TS200: 0x0214	HPT5K0TS200: 0x0014	HPT5K0TS200-L: 0x8014


Appendix C: Install/Update XP USB I²C Device Driver

1. If not already there, copy the entire directory (XPPowerWinUSBdrv) of the new XP USB I²C device driver to C:\Program Files (x86)\XP Power\XP PS Manager\XPPowerWinUSBdrv.
2. Connect XP USB I²C device to PC.


3. NOTE:

- Skip this step if 'XP Power Interface CDC' has been installed (go to step 4).
- For Windows 10, see step 9 below.

Once Windows finished installing available drivers, CDC driver is left.




Open 'Control Panel, Device Manager', locate 'XP Power Interface CDC' and right click on it.




- a. If available, select 'Update Driver Software' otherwise select 'Property', 'Driver' tab, 'Update Driver' button.
- b. 'Browse to C:\Program Files (x86)\XP Power\XP PS Manager\XPPowerWinUSBdrv directory, ensure that 'Include subfolders' box is checked.
- c. Click 'Next' button to update driver.

Once the CDC driver is installed, you'll have new 'Virtual COM' device, shown in the following steps and CDC device will disappeared from Device Manager list.


4. Locate 'XP Power Virtual COM' device under 'Ports', right click on it.
If available, select 'Update driver'....




... otherwise, select 'Property', 'Driver' tab, click on 'Update driver'.




5. Select 'Browse my computer'



6. Browse to
C:\Program Files (x86)\XP Power\XP PS Manager\XPPowerWinUSBdrv directory, ensure that 'Include subfolders' box is checked.
Click 'Next' button, update process begins.




7. Once update process is completed, locate 'WinUsb Device'. It may be under other device folder, repeat step 4-6



8. Once the update for 'WinUsb Device' process is completed, close all opened control windows. Driver software Installation/update is completed.


9. **For Windows 10**

Click on 'Settings' icon




On the 'Setting' window, type 'Device Manager' and press 'Enter' key.


Windows Settings



On device Manager window,

Right click on 'XP Power Interface I2C' and select 'Update Driver'.






Select 'Browse my computer' and follow step 6 above.

Appendix D: Things to remember

1. Enable write command.
2. If you add/remove power supply on the bus, click 'Scan Bus' button.
3. Might want to click 'Stop Loop' before switching to SCPI tab.
4. 'Scan' buttons and 'MultiUnit' tab are not functional while in SCPI protocol.
5. PICkit Serial USB adapter only work with I²C/PMBus communication.
6. Switch interface cable when you switch communication port.
7. When changing communication port, verify 'parity', default is 'Even'.

Appendix E: PMBus Status Bits Reference

Status Summary:



STATUS_WORD

Byte	Bit Number	Status Bit Name	Meaning
Low	7	BUSY	A fault was declared because the device was busy and unable to respond.
	6	OFF	This bit is asserted if the unit is not providing power to the output, regardless of the reason, including simply not being enabled.
	5	VOUT_OV	An output overvoltage fault has occurred
	4	IOUT_OC	An output overcurrent fault has occurred
	3	VIN_UV	An input undervoltage fault has occurred
	2	TEMPER- ATURE	A temperature fault or warning has occurred
	1	CML	A communications, memory or logic fault has occurred
	0	NONE OF THE ABOVE	A fault or warning not listed in bits [7:1] of this byte has occurred
High	7	VOUT	An output voltage fault or warning has occurred
	6	IOUT/POUT	An output current or output power fault or warning has occurred
	5	INPUT	An input voltage, input current, or input power fault or warning has occurred
	4	MFR	A manufacturer specific fault or warning has occurred
	3	POWER_ GOOD#	The POWER_GOOD signal, if present, is negated
	2	FANS	A fan or airflow fault or warning has occurred
	1	OTHER	A bit in STATUS_OTHER is set
	0	UNKNOWN	A fault type not given in bits [15:1] of the STATUS_WORD has been detected

STATUS_VOUT

Bit	Meaning
7	VOUT Overvoltage Fault
6	VOUT Overvoltage Warning
5	VOUT Undervoltage Warning
4	VOUT Undervoltage Fault
3	VOUT_MAX Warning (An attempt has been made to set the output voltage to value higher than allowed by the VOUT_MAX command (Section 13.5).
2	TON_MAX_FAULT
1	TOFF_MAX Warning
0	VOUT Tracking Error [1]

STATUS_IOUT

Bit	Meaning
7	IOUT Overcurrent Fault
6	IOUT Overcurrent And Low Voltage Shutdown Fault
5	IOUT Overcurrent Warning
4	IOUT Undercurrent Fault
3	Current Share Fault [1]
2	Power Limiting [2]
1	POUT Overpower Fault
0	POUT Overpower Warning

STATUS_INPUT

Bit	Meaning
7	VIN Overvoltage Fault
6	VIN Overvoltage Warning
5	VIN Undervoltage Warning
4	VIN Undervoltage Fault
3	Unit Is Off For Insufficient Input Voltage [1]
2	IIN Overcurrent Fault
1	IIN Overcurrent Warning
0	PIN Overpower Warning

STATUS_TEMPERATURE

Bit	Meaning
7	Overtemperature Fault
6	Overtemperature Warning
5	Undertemperature Warning
4	Undertemperature Fault
3	Reserved
2	Reserved
1	Reserved
0	Reserved

STATUS_CML

Bit	Meaning
7	Invalid Or Unsupported Command Received
6	Invalid Or Unsupported Data Received
5	Packet Error Check Failed
4	Memory Fault Detected [1]
3	Processor Fault Detected [2]
2	Reserved
1	A communication fault other than the ones listed in this table has occurred
0	Other Memory Or Logic Fault has occurred. [3]

STATUS_OTHER

Bit	Meaning
7	Reserved (Replaced by STATUS_FANS)
6	Reserved (Replaced By STATUS_FANS)
5	Input A Fuse Or Circuit Breaker Fault [1]
4	Input B Fuse Or Circuit Breaker Fault [1]
3	Input A OR-ing Device Fault [2]
2	Input B OR-ing Device Fault [2]
1	Output OR-ing Device Fault [3]
0	Reserved

STATUS_FAN_1_2

Bit	Meaning
7	Fan 1 Fault [1]
6	Fan 2 Fault [1]
5	Fan 1 Warning [2]
4	Fan 2 Warning [2]
3	Fan 1 Speed Overridden [3]
2	Fan 2 Speed Overridden [3]
1	Airflow Fault [4]
0	Airflow Warning [4]

Appendix F: XP USB I2C Cable Diagrams




Figure F-1: RS485 Half Duplex connections.

Note: 1. Use I²C connection to configure RS485 port (full or half duplex) then switch connection.

See section 4.1.2.1 for details.

2. Optional: For ease of use (switching back and forth, comm test, etc.), combine I²C connection with another connection. See section 4.1.2.2.2 for details.




Figure F-2: RS485 Full Duplex connections.




Figure F-3: CAN connections.




Figure F-4: RS232 connections.




Figure F-5: Optional RS232 connection diagrams.

Note: This connection is not compatible with XP Power Supplies Manager.

- Note:**
1. Combination of I²C and RS485 (full or half duplex) connections is a convenient cable to use when switching interface (i.e. I²C to RS485). Similarly, I²C and CAN, I²C and RS232 cables are valid combination cables.
 2. In Multi-Unit connection, I²C bus is held down by an un-powered unit and 'No Power Supply Found' is displayed in 'Monitor' tab, 'Slave Adr List' textbox.

Appendix G: Change Log

Rev 2.14

- Add more bootloader error handling/display logic.
- Delete bootloader 'Verify' button.
- Fixed the need to have 'Read Loop' running while in bootloader mode.
- Added more primary specific BL error detection.
- Correct double display of "ProgramBlockOK @: xxxx".
- In 'UpdateFirmware' tab, verify that selected secondary f/w file name match h/w model number.
- Bootloader.cs: Clean up commented-out code
- Bootloader.cs: Add function separator (//====....)
- Add logic to detect primary mismatch f/w file & h/w (using filename & h/w model name).
- Naming convention: (for XP PS Mngr 2.14 version)
 - Primary Bootloader model name (hard coded) must contain 3 letters of the h/w model (HPA, HPF, HPT, etc).
 - Primary app file name must contain 3 letters of the h/w model (HPA, HPF, HPT, etc).
 - Secondary file name must contain full model number (HPA1K5PS60, HPT5K0TS060, etc.)

Rev 2.13

- Added support for current ramp up/down (0xDB, 0xDD) command codes.
- Fixed formatting for READ_OUTPUT, READ_CONFIGURATION commands.
- Add checksum print on secondary firmware update completion
- Add error prompt if checksum values are mismatching, tell user there is an issue.
- Make 'BootLoader' tap page, 'Target Level' into 'Select Process' drop down menu.
- Rearrange 'BootLoader' tap page layout.

Rev2.12

- Fixed Primary f/w update bug:
 - >> slow down when writing to FLASH
 - >> Add pause between Enter BL to Erase to Pgm operations.
- Following window size got reduced, increased size back to original:
 - Configure Tab, Communication Log window
 - SCPI tab, SCPI Error Log window
 - Calibration tab, Communication Log windows
- Added missing parameters logic for 'Write' & 'Read' btns in 'PMBusUtil' tab.
- New 'Loop Delay' logic, share same txtbox with 'GFR'.
- Removed PFC1-3 from Update_F/w menu; Primary & Secondary operation only.
- Save factory Data >> using btnEraseAppFlash_Click()
- New 'OK2Update' logic >> multiple units updates with out reselecting 'operation' & f/w file.
- Minor bug when update Primary f/w, bootloader did not restart, must 'Enter' bootloader & 'Exit' again.
- Change f/w file size in Update f/w check logic
- Publish factory & user installation package
- Added logic to check selected firmware file match the operation (primary/secondary) selected.

- Rev 2.11

- Adjust byte_num read cmd for PICKit or XP_USB interface, in Utility tab.
- Install this app under 'XP Power' folder.